

Thank you for purchasing this Dynojet kit. This kit has been developed for a motorcycle which is set to the parameters listed at the right in the "Stage" description. If your motorcycle does not meet any of these parameters please check with Dynojet before installation. For technical assistance contact your Dynojet distributor or call Dynojet U.S.A. (800)-992-4993

2191 Mendenhall Dr. Suite 105
North Las Vegas, NV 89031
TEL: 702-399-1423
FAX: 702-399-1431
8am-5pm Pacific Time
Monday through Friday

Website Address
<http://www.dynojet.com>

The manufacturer and seller make no warranties express or implied which extend beyond the description of the goods contained herein. Any description of this product is for the purpose of identifying it and shall not be deemed to create an express warranty.



2108.003

U.S Models Only

1984-86 Kawasaki ZX900

Stage 1&3


STAGE 1

For mildly tuned machines using the stock airbox, with stock or K&N filter #KA-9084

STAGE 3

For mildly tuned machines using individual filters or velocity stacks. K&N filters #RC-2814

Both stages may be used with a good aftermarket exhaust



This graph shows a typical gain with a Dynojet jet kit.

WARNING

**NO SMOKING!
NO OPEN FLAME!
WHILE INSTALLING
YOUR DYNJOET KIT**

Parts List		
4	Main Jets	DJ120
4	Main Jets	DJ116
4	Main Jets	DJ136
4	Main Jets	DJ140
1	Slide Drill	DD #31
4	Fuel Needles	DNO228
8	Adjusting Washers	DW0001
4	E-Clips	DE0001
4	Slide Springs	DSP005
1	Plug Drill	DD #5/32
1	Screw	DS0001

STAGE ONE INSTRUCTIONS

1. Remove the vacuum slide from the carbs. Remove the stock needles & spacers, noting the order of assembly.
2. Use the drill (DD# 31) provided to enlarge slide lift hole (Fig. A).
3. Install the Dynojet needles on groove #2, using all stock spacers (Fig. A). Install the adjusting washers (2 per needle), above the e-clip.
4. Install the Dynojet slide springs in place of the stock slide springs.
5. Remove the main jet and replace with the Dynojet main jets provided. Use the DJ116 main jets with stock exhaust, or use the DJ120 main jets with aftermarket headers or slip-ons with free flowing baffles. Be sure that the jet you are changing is the main jet.
6. Locate the fuel mixture plug (Fig. B), if you see a screw head, proceed to adjusting procedure. With the 5/32 drill provided, carefully drill thru the plugs. NOTE: the mixture screw is directly underneath this plug, be ready to pull back on the drill the instant you break thru. Use screw provided to secure and remove the plug. Carefully turn mixture screw clockwise until seated, then back out 4 turns.

STAGE THREE INSTRUCTIONS

1. Remove the vacuum slide from the carbs. Remove the stock needles & spacers, noting the order of assembly.
2. Use the drill (DD #31) provided to enlarge slide lift hole (Fig. A).
3. Install the Dynojet needles on groove #2, using all stock spacers (Fig. A). Install the adjusting washers (2 per needle), above the e-clip.
4. Install the Dynojet slide springs in place of the stock slide springs.
5. Remove the main jet and replace with the Dynojet main jets provided. Use the DJ116 main jets with stock exhaust, or use the DJ136 main jets with aftermarket headers or slip-ons with free flowing baffles. Be sure that the jet you are changing is the main jet.
6. Locate the fuel mixture plug (Fig. B), if you see a screw head, proceed to adjusting procedure. With the 5/32 drill provided, carefully drill thru the plugs. NOTE: the mixture screw is directly underneath this plug, be ready to pull back on the drill the instant you break thru. Use screw provided to secure and remove the plug. Carefully turn mixture screw clockwise until seated, then back out 4 turns.

Fig. A




Fig. B

