

TRAILING ARM SKID PLATE

2024+ TOYOTA TACOMA

SPTT1-07



TOOLS REQUIRED

- Heavy duty ratchet strap
- 18, 19mm sockets
- 18, 19mm wrenches
- Rubber mallet

SKILL LEVEL

- Novice/Intermediate
- 1 (you) to 2 persons

Little skill level required, you can easily install it by yourself however, additional help will be useful

TIME REQUIRED

- 1.5 Hours

Time to install this should only take about one and half hours

WARNINGS/CAUTIONS BEFORE STARTING INSTALLATION

Before you install this kit — Read and understand all instructions, warnings, cautions, and notes contained in this installation instruction guide. Consult your vehicle owner's manual for proper disconnection of electrical and lifting of vehicle if required for installation of this product.

This install may require some technical skills and knowledge of basic mechanical work. If you do not feel that you are capable of performing this install please take this product to a trained professional.

After reading this guide please contact us with any questions or concerns before installing product.

Customer Service: 855-680-9595

DV8 Offroad is not responsible for any bodily injury or harm to you or your vehicle as a result of an improper install.

Proper installation of this kit required knowledge of the factory recommended procedures for removal and installation of original equipment components. We recommend that the factory shop manual and any special tools needed to service your vehicle be on hand during the installation. Installation of this kit without proper knowledge of the factory recommended procedures may affect the performance of these components and the safety of the vehicle

- Always wear eye protection when operating power tools

Inspect all contents of this package to make sure product is not damaged and all installation hardware has been included. If parts are missing from kit, please be prepared to provide the following information

1. Name of purchase location
2. Bar Code on side of box
3. Date above bar code
4. Date inside box cover



INSTALLATION MANUAL

Begin by unpacking all items and inspecting for missing pieces or damage. If you have any concerns, please contact the company the product was purchased from. Extra hardware may be included with the product.

HARDWARE INCLUDED

- (2) Hex Bolts
- (4) M12 Washers
- (2) Nylon Lock Nuts



STEP 1 | Use a ratchet strap and connect the rear axle towards the rear of the vehicle. We connected the rear axle to the hitch. This will prevent shifting of the axle.

This can be done on a lift or on the ground with the tire lifted on a floor jack.

Each side will need to be strapped as you install the respective skid plate.



STEP 2 | Use a 19mm socket and wrench to remove the trailing arm bolt and nut.

NOTE: If the bolt is difficult to move, use the ratchet strap to adjust the tension on the bolt. The bolt should easily come out.



INSTALLATION MANUAL

STEP 3 | With the bolt removed, place the DV8 Trailing arm skid plate in position over the factory mount.



STEP 4 | Place the skid plate towards the front of the trailing arm, slide the skid plate up and back ensuring the skid plates welded spacer sits in front of (towards the front of the vehicle) the lip that on the trailing arm mount (red arrow).

NOTE: You may need to lightly tap the skid plate into place with a mallet.



STEP 5 | With the skid plate in position loosely secure the skid plate in place using the factory hardware.





STEP 6 | Using the provided M12 bolts, install the bolt into the upper mounting hole of the skid plate through the hole on the mount.



STEP 7 | Using a 18mm socket and 19mm wrench, tighten the upper bolt until secure.

Using the same 19mm tools, torque the link bolt to 103 ft. lbs.



INSTALLATION MANUAL

STEP 8 | Once complete, repeat process for other side.

Double check all hardware is secure and there is no binding or contact from the link and new skid plate.

Congratulations you are done with the install of the DV8 24+ Tacoma Trailing arm skid plates!

