

# HOW TO INSTALL: TOYOTA TACOMA LOWER CONTROL ARM SKID PLATE



## HARDWARE LIST

- (2) Aluminum Spacer
- (2) 1/4 Lock Nut
- (4) 3/8 Lock Nut
- (4) 3/8 Washer
- (2) 1/4 Washer
- (2) 1/4 Washer Oversized
- (2) 1/4-20 Bolt, 3.5" Long
- (2) 3/8-16 Carriage Bolt, 3" Long
- (2) 3/8-16 Carriage Bolt, 3.5" Long

### Step 1



First you will need to remove the plastic caps that are located on the lower control arm. Use can use a flat screwdriver or pry bar to remove them.

### Step 2



Locate the holes that align with the Lower Control Arm Skid.

### Step 3




Using the shorter 3/8 carriage bolt, place it into position towards the front of the skid plate. Push it through the lower control arm and put on a washer and a nut. Hand tighten.

### Step 4



Using the longer 3/8 carriage bolt, place it into position towards the rear of the skid plate. Push it through the lower control arm and put on a washer and a nut. Hand tighten.

### Step 5



Place the aluminum spacer between the skid plate and the lower control arm.

### Step 6



Use the 1/4" bolt, add a washer, push the bolt through the skid and through the aluminum spacer. Note: Only the 2nd Gen Tacoma will require the aluminum spacer.

## Step 7



Place the remaining nut onto the 1/4" bolt, and tighten. Note: This is best installed with the vehicle on the ground. Once all the bolts are in place - tighten down all the bolts.