

OFF-ROAD Installations



@MTSOFFROAD

TECH SUPPORT:
(602) 272-5009

INFO@MTSOFFROAD.COM

POLARIS
RZR
SPRING KIT

YEAR	MODEL	SEAT	SHOCK TYPE
2014 - 2017	XP 1000 / TURBO	2	WALKER EVANS

DISASSEMBLY

FRONT SHOCK & SPRING REMOVAL

1. Jack up the front of the car until arms are at full droop (fully extended)
2. Loosen the top shock bolt 15 mm
3. Loosen the bottom shock bolt 15 mm. Save all factory hardware - It will be reused later during the install process
4. Repeat steps 2 and 3 for the opposite side
5. Remove shocks from car (make sure jack is secured)
6. Compress front springs for removal

Tech Tip: Use the flat blade of a screwdriver to pry down foam bump stop. It is important to not damage or scratch the shock shaft during this process


7. Remove factory spring perch and all springs. Keep all spring perches together
8. Remove and discard the factory spring divider. This is the plastic piece separating the springs and it will be replaced with a new MTS Off-Road Spring Divider that has been provided in your Spring Kit
9. Repeat steps 6 - 8 for the opposite side

REAR SHOCK & SPRING REMOVAL

10. Jack up the rear of the car until arms are at full droop (fully extended)
11. Loosen all 4 rear shock bolts 18 mm. Save all factory hardware - It will be reused later during the install process
12. Compress rear springs for removal

Tech Tip: Use the flat blade of a screwdriver to pry down foam bump stop. It is important to not damage or scratch the shock shaft during this process

13. Remove factory spring perch and all springs. Keep all spring perches together
14. Remove and discard the factory spring divider. This is the plastic piece separating the springs and it will be replaced with a new MTS Off-Road Spring Divider that has been provided in your Spring Kit
15. Repeat steps 12 - 14 for the opposite side



OFF-ROAD Installations



@MTSOFFROAD

TECH SUPPORT:
(602) 272-5009

INFO@MTSOFFROAD.COM

POLARIS
RZR
SPRING KIT

YEAR

2014 - 2017

MODEL

XP 1000 / TURBO

SEAT

2

SHOCK TYPE

WALKER EVANS

SET ADJUSTMENTS

PRELOAD & CROSSOVER MEASUREMENTS

16. Set the preload for all front and rear shocks by measuring from shock end cap to spring contact point
17. Set the crossover ring measurement for all the front shocks by measuring the shock end cap to crossover ring contact point
18. Tighten crossover ring screws 7/64"

PRELOAD

FRONT

3"

REAR

4 1/4"

CROSSOVER


FRONT

7"

REAR


10 1/4"

CROSSOVER RING
MEASUREMENT



PRELOAD
MEASUREMENT

TECH SUPPORT: INFO@MTSOFFROAD.COM | (602) 272-5009 | FOLLOW: @MTSOFFROAD



OFF-ROAD Installations



@MTSOFFROAD

TECH SUPPORT:
(602) 272-5009

INFO@MTSOFFROAD.COM

POLARIS
RZR
SPRING KIT

YEAR	MODEL	SEAT	SHOCK TYPE
2014 - 2017	XP 1000 / TURBO	2	WALKER EVANS

INSTALLATION

FRONT SPRING ASSEMBLY

19. Assemble the front shock with new tender spring on first
20. Install new spring dividers that is provided in your Spring Kit with the shorter end closest to the cross over ring (top of shock)
21. Install new main spring by rotating (clocking) the spring ends 180 degrees so they are on the opposite sides of the spring divider
22. Compress spring assembly and install spring perch
23. Release spring tension from spring assembly
24. Repeat steps 19 - 23 for the opposite side

FRONT SHOCK INSTALL


25. Reinstall the front shocks using your factory hardware that was saved from the disassembly. Do not tighten factory bolts yet - the shocks may have to come off of the car for later adjustments. Your reservoir should be facing towards the rear of the car. Keep washer and nylock nuts together for final adjustments

REAR SPRING ASSEMBLY

26. Assemble the rear shock with new tender spring on top
27. Install new spring dividers that is provided in your Spring Kit with the shorter end closest to the cross over ring (top of shock)
28. Install new main spring by rotating (clocking) the spring ends 180 degrees so they are on the opposite sides of the spring divider
29. Compress spring assembly, install spring perch and rock guard
30. Release spring tension from spring assembly
31. Repeat steps 26 - 30 for the opposite side

REAR SHOCK INSTALL

32. Reinstall the rear shocks using your factory hardware that was saved from the disassembly. Do not tighten factory bolts yet, the shocks may have to come off of the car for later adjustments



OFF-ROAD Installations



@MTSOFFROAD

TECH SUPPORT:
(602) 272-5009
INFO@MTSOFFROAD.COM

POLARIS
RZR
SPRING KIT

YEAR	MODEL	SEAT	SHOCK TYPE
2014 - 2017	XP 1000 / TURBO	2	WALKER EVANS

FINAL ADJUSTMENTS

33. Settle the car by driving it in reverse and then forward at least 15 feet, so the suspension can be settled into place
34. Find the axle angle using an angle finder

Tech Tip: Use your smartphone to measure the axle angle with the free easy to use mobile app called "Measure".

If you own an Android - you will need to download the "Measure" app.

If you own an iPhone - the "Measure" app should already be installed onto your mobile device



35. Your front and rear axles should measure to **14 degrees** (+ or - 1 degree). If your axle angle is less than **14 degrees** then increase the preload, if it is more than **14 degrees** then decrease the preload

WARNING: If your measurements do not meet the target axle angle, then your car will not perform properly

36. After the target axle angle has been met, tighten bolts utilizing factory hardware. You should not have any extra hardware left over at this point
37. Double check your work and enjoy the ride

TECH SUPPORT: INFO@MTSOFFROAD.COM | (602) 272-5009 | FOLLOW: @MTSOFFROAD